

# Fitting Instructions - Bottle Holder

1. Instruction 2 to 5 only apply if your GoKart has standard speed control. Number 6 only applies if you have the Automatic control.

2. Take the handle bracket, loosen the two screws and separate the two halves of the bracket (photo A).

3. Make sure the two nuts are in position in the inner part of the handle bracket (photo B).

4. Hold the inner section of the handle bracket in position at the top of the handle, and slide the outer section over it (photo C). It can be fitted to either side of the handle.

5. Re-fit and tighten the two screws in the handle bracket (photo D).

6. Use a coin to remove one of the blanking plugs which are on either side of the Automatic upper frame (photo E).

7. Screw the bottle holder mount into the handle bracket or the mounting point on the automatic (photo F).

8. Clip the bottle holder to the mount (photo G).

9. Before folding your GoKart for storage, it's better to firstly unclip the bottle holder.

10. The bottle holder mount can be left on the trolley permanently.

