
Fitting Instructions - Front wheel bearings



- 1. The easiest way to attack the front wheel is to unfold the trolley, fit the battery and tip it so the handle rests on the ground (picture 1).
- 2. Holding both the round nuts either side of the wheel, twist anti-clockwise until one side unscrews (picture 2).
- 3. Remove the loose nut completely and withdraw the front wheel spindle (picture 3). If it sticks, give it a tap with a mallet or block of wood.
- 4. Remove the front wheel and clear any grass or mud that has collected in the centre.
- 5. Remove the old bearings from the centre of the wheel (picture 4).
- 6. Fit the new bearings into the front wheel. They can be simply pressed home (picture 5).
- 7. Fit one of the new round nuts to the new spindle.
- 8. Position the bag support over the front forks and insert the new spindle through one side (picture 6).
- 9. Position the front wheel between the forks and push the spindle all the way through (picture 7).
- 10. Re-fit the remaining round nut; twisting them against each other, hand tighten firmly (picture 8).

Please call us if you have any difficulty



GoKart Electric Golf Eagle House, Lakesview Business Park, Canterbury, CT3 4JZ T 01227 712288 F 01227 710808 E go@gokart.co.uk